

NOTICE DE MONTAGE

ECOPES DE RADIATEUR ERMAX ADAPTABLES SUR GSR 600 2006 → ∞



Position du joint caoutchouc

Kit de fixation

- 4 vis BHc 6×25 (petite tête)
- 4 entretoises Ø6 L : 10mm
- 2 morceaux de grille alu
- 4 rondelles plastique Ø6
- 40 cm de joint caoutchouc

Montage

- Démontez les caches radiateur d'origine. Collez la moitié du joint caoutchouc sur chaque écope, sur le bord qui sera en contact avec le réservoir (voir photo).
- Positionnez les écopes sur la moto et fixez-les avec les vis et rondelles fournies en insérant les entretoises entre le radiateur et les écopes.
- Les grilles aluminium sont une option. Elles se placent au niveau des entrées d'air avec de la colle à pare-brise (colle polyuréthane).

« ATTENTION »

* Les pièces peintes et vernies ne sont pas garanties contre les lavages vapeur « haute pression » ou les produits nettoyants agressifs qui peuvent les endommager et décoller le vernis. Nous conseillons d'ailleurs, d'après les données techniques de nos fournisseurs en peinture, d'**attendre un mois** afin d'obtenir une polymérisation complète du vernis.

* Tout accessoire monté ne sera plus considéré comme neuf et ne sera **ni repris ni échangé**.

* Les accessoires Ermax sont conçus pour des **montes d'origine**. Ils ne seront pas garantis s'ils sont utilisés dans d'autres conditions.

* En raison des tolérances de fabrication des véhicules, indépendantes de notre volonté, certains produits Ermax peuvent nécessiter des ajustements lors de la fixation.

* Attention aux serrages excessifs qui pourraient abîmer ou casser nos accessoires en plastique et les vis en aluminium

* Les marques de fabricant de motos citées sont indiquées exclusivement comme référence nécessaire à la destination des accessoires Ermax.

FITTING INSTRUCTIONS

ERMAX SCOOPS
ADAPTABLE ON GSR 600 2006 → ∞



Rubber seal location

Fitting kit

- 4 BHc 6x25 screws
- 4 Ø6 washers
- 4 Ø6 L : 10mm spacers
- 40 cm of rubber seal
- 2 pieces of aluminium railings

Assembly

- Remove the original radiator covers. Stick the half of the rubber seal on both edges of scoops that will be in touch with the gas tank (see photo).
- Place the scoops on the motorbike and fit them with the provided screws and washers by inserting the spacers between the radiator and scoops.
- Aluminium railings are one option. They take place at the air intakes with stick for windshield (polyurethane stick).

« ATTENTION »

- * Painted and varnished parts are not guaranteed against high pressure steam washes or aggressive cleaning products which can damage them and unstuck the varnish. We advise moreover, according to the technical data of our painting suppliers, **to wait one month** to obtain a complete polymerization of varnish.
- * Accessories gone up on the motorbike will not be any more considered as new and will be **neither retaken nor exchanged**.
- * Ermax accessories are foreseen for **original equipments**. They will not be guaranteed if they are used in others conditions.
- * Due to vehicles made tolerances, beyond our control, some Ermax products might need adjustments to fit.
- * Care to excessive clampings which may damage or break our plastic accessories and aluminium screws.
- * The mentioned label of motorbikes' manufacturers are indicated exclusively as a reference to Ermax accessories.